

# Altro accessory information

AltroMastic™ 100

November 2019

|                             |                                                                        |
|-----------------------------|------------------------------------------------------------------------|
| <b>Viscosity:</b>           | Thixotropic                                                            |
| <b>Density:</b>             | 1.01                                                                   |
| <b>Cure Time:</b>           | 24-48 hours                                                            |
| <b>Skin Time:</b>           | 20 minutes                                                             |
| <b>Storage:</b>             | Store between 5°C to 25°C in cool, dry conditions                      |
| <b>Shelf Life:</b>          | At least 12 months, in an airtight container, from date of manufacture |
| <b>Coverage:</b>            | Approximately 40 linear meters per 3mm bead                            |
| <b>Working Temperature:</b> | Between 5°C to 40°C                                                    |
| <b>Full Bond:</b>           | 4 days                                                                 |
| <b>Contains:</b>            | 290ml                                                                  |

## Instructions for use

1. AltroMastic 100 is a specially formulated sealing compound for use where Altro floorings abutt edges, skirtings, wall surfaces etc, or where the flooring is cut around pipes, upstands door frames etc.
2. AltroMastic 100 is not recommended for use in trafficked areas, as a welded joint will give superior performance. Where flooring abutts drainage channels, access covers, quarry tiles etc, a clamping or welding system should be used. Please refer to Altro for detailing sheets.
3. AltroMastic 100 should only be used to seal joints in Altro floorings where obstructions prevent the use of a hot air welding gun.

## Procedure

1. Surfaces to be sealed must be dry and free from dirt, oil or grease.
2. All areas to be sealed should be masked with the masking tape supplied.
3. Place tube of sealant into skeleton gun.
4. Cut off the end of the tube nipple, fix the nozzle, and apply a bead approximately 3mm in diameter.
5. Once opened the curing process begins, therefore, open tubes may not be reused as the mastic may have cured within the tube.
6. Remove masking tape as soon as possible as AltroMastic 100 is formulated to be fast curing.

## Health and safety advice

Before using this adhesive, users should refer to the SDS (Safety Data Sheet) for correct safety advice and to determine the level of PPE (Personal Protective Equipment) and RPE (Respiratory Protective Equipment) that is required.

A COSHH (Control of Substances Hazardous to Health) assessment and risk assessment should be carried out before using this adhesive.

In the case of contact with eyes or skin, rinse immediately with plenty of water and seek medical advice.

For further information see SDS available from Altro.

## Product for professional use

Although the technical details and recommendations contained in this product datasheet correspond to the best of our knowledge and experience, all the above information must be taken as merely indicative and subject to confirmation after long-term practical application: for this reason, anyone who intends to use the product must ensure beforehand that it is suitable for the envisaged application: in every case, the user alone is fully responsible for any consequences deriving from the use of the product.